
1969 AMC REBEL



CINCO

1969 AMC REBEL
MAIN POWER

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
FUSIBLE LINK
COIL
HORN
STARTER SOLENOID
OIL PRESS. SWITCH
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
HORN
HORN RELAY
BRAKE LIGHT SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
HAZARD FLASHER
FLASHER
FUSE BLOCK
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
WIPER SWITCH FEED
ASHTRAY LIGHT
HEADLIGHT WARNING BUZZER
BRAKE FAILURE WARNING SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
IGN. SWITCH & CIG. LIGHTER LIGHT
HEATER LIGHT
CLOCK & LIGHT
HEADLIGHT SWITCH
DOOR SWITCH
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
TRUNK LIGHT
FUEL LEVEL SENDER
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT
TAIL LIGHT (EXCEPT WAGON)
LICENSE PLATE LAMP
TEMP. SENDER
DIMMER SWITCH


CINCO

1969 AMC REBEL
ACCESSORY POWER

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
STARTER SOLENOID
COIL
HORN
OIL PRESS. SWITCH
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
HAZARD FLASHER
FLASHER
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
FUSE BLOCK
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
WIPER SWITCH FEED
ASHTRAY LIGHT
HEADLIGHT WARNING BUZZER
HORN
HORN RELAY
BRAKE LIGHT SWITCH
TURN SIGNAL
PARK LAMP
HIGH BEAM
DUAL BEAM
SIDE LIGHT
TEMP. SENDER
DIMMER SWITCH
BRAKE FAILURE WARNING SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
DOOR SWITCH
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
FROM BATTERY
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
IGN. SWITCH & CIG. LIGHTER LIGHT
HEATER LIGHT
CLOCK & LIGHT
HEADLIGHT SWITCH
DOOR SWITCH
COURTESY LIGHT
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT
TAIL LIGHT (EXCEPT WAGON)
LICENSE PLATE LAMP
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
TRUNK LIGHT
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
FUEL LEVEL SENDER
TAIL LIGHT (EXCEPT WAGON)
BRAKE LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT


CINCO

1969 AMC REBEL
IGNITION SYSTEM




CINCO

1969 AMC REBEL
STARTING SYSTEM




CINCO

1969 AMC REBEL
CHARGING SYSTEM




CINCO

1969 AMC REBEL
HEADLIGHTS




CINCO

1969 AMC REBEL
RUNNING LIGHTS




CINCO

1969 AMC REBEL
BRAKE LIGHTS



CINCO

1969 AMC REBEL
TURN SIGNALS



CINCO

1969 AMC REBEL
HEATER

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
STARTER SOLENOID
COIL
HORN
OIL PRESS. SWITCH
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
HORN
HORN RELAY
BRAKE LIGHT SWITCH
TURN SIGNAL
PARK LAMP
HIGH BEAM
DUAL BEAM
SIDE LIGHT
TEMP. SENDER
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
HAZARD FLASHER
FLASHER
FUSE BLOCK
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
DIMMER SWITCH
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
WIPER SWITCH FEED
ASHTRAY LIGHT
HEADLIGHT WARNING BUZZER
BRAKE FAILURE WARNING SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
DOOR SWITCH
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
IGN. SWITCH & CIG. LIGHTER LIGHT
HEATER LIGHT
CLOCK & LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT
DOOR SWITCH
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT (EXCEPT WAGON)
TAIL LIGHT
LICENSE PLATE LAMP
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
TRUNK LIGHT
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
FUEL LEVEL SENDER
TAIL LIGHT (EXCEPT WAGON)
BRAKE LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT

CINCO

1969 AMC REBEL
HORN

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
STARTER SOLENOID
FUSIBLE LINK
COIL
HORN
OIL PRESS. SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
HAZARD FLASHER
FLASHER
HORN
HORN RELAY
BRAKE LIGHT SWITCH
FUSE BLOCK
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
WIPER SWITCH FEED
ASHTRAY LIGHT
HEADLIGHT WARNING BUZZER
BRAKE FAILURE WARNING SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
DOOR SWITCH
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
IGN. SWITCH & CIG. LIGHTER LIGHT
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT
TAIL LIGHT (EXCEPT WAGON)
LICENSE PLATE LAMP
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
TRUNK LIGHT
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
FUEL LEVEL SENDER
HEATER LIGHT
CLOCK & LIGHT
HEADLIGHT SWITCH
DOOR SWITCH
COURTESY LIGHT
TAIL LIGHT (EXCEPT WAGON)
BRAKE LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
TURN SIGNAL
PARK LAMP
HIGH BEAM
DUAL BEAM
SIDE LIGHT
TEMP. SENDER
DIMMER SWITCH

CINCO

1969 AMC REBEL
TRANSMISSION

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
STARTER SOLENOID
COIL
HORN
OIL PRESS. SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
HAZARD FLASHER
FLASHER
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
BRAKE FAILURE WARNING SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
DOOR SWITCH
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
IGN. SWITCH & CIG. LIGHTER LIGHT
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT
EXCEPT WAGON
TAIL LIGHT
LICENSE PLATE LAMP
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
TRUNK LIGHT
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
FUEL LEVEL SENDER
HEATER LIGHT
CLOCK & LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT
DOOR SWITCH
TAIL LIGHT
EXCEPT WAGON
BRAKE LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
HORN
HORN RELAY
BRAKE LIGHT SWITCH
FUSE BLOCK
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
ASHTRAY LIGHT
WIPER SWITCH FEED
HEADLIGHT WARNING BUZZER
TURN SIGNAL
PARK LAMP
HIGH BEAM
DUAL BEAM
SIDE LIGHT
TEMP. SENDER
DIMMER SWITCH

CINCO

1969 AMC REBEL
GAUGES & WARNING LIGHTS

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
STARTER SOLENOID
COIL
HORN
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
OIL PRESS. SWITCH
HAZARD FLASHER
FLASHER
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
BRAKE FAILURE WARNING SWITCH
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
HEADLIGHT WARNING BUZZER
WIPER SWITCH FEED
ASHTRAY LIGHT
FUSE BLOCK
HORN
HORN RELAY
BRAKE LIGHT SWITCH
TEMP. SENDER
DIMMER SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
IGN. SWITCH & CIG. LIGHTER LIGHT
DOOR SWITCH
HEATER LIGHT
CLOCK & LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT
DOOR SWITCH
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
TRUNK LIGHT
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
FUEL LEVEL SENDER
LICENSE PLATE LAMP
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT
TAIL LIGHT (EXCEPT WAGON)
TURN SIGNAL
PARK LAMP
HIGH BEAM
DUAL BEAM
SIDE LIGHT
TAIL LIGHT (EXCEPT WAGON)
BRAKE LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT

CINCO

1969 AMC REBEL
REVERSE LIGHTS

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
STARTER SOLENOID
COIL
HORN
OIL PRESS. SWITCH
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
HAZARD FLASHER
FLASHER
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
BRAKE FAILURE WARNING SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
DOOR SWITCH
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
IGN. SWITCH & CIG. LIGHTER LIGHT
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT
TAIL LIGHT (EXCEPT WAGON)
LICENSE PLATE LAMP
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
TRUNK LIGHT
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
FUEL LEVEL SENDER
HEATER LIGHT
CLOCK & LIGHT
HEADLIGHT SWITCH
COURTESY LIGHT
DOOR SWITCH
TAIL LIGHT (EXCEPT WAGON)
BRAKE LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
HORN
HORN RELAY
BRAKE LIGHT SWITCH
FUSE BLOCK
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
ASHTRAY LIGHT
WIPER SWITCH FEED
HEADLIGHT WARNING BUZZER
TURN SIGNAL
PARK LAMP
HIGH BEAM
DUAL BEAM
SIDE LIGHT
TEMP. SENDER
DIMMER SWITCH


CINCO

1969 AMC REBEL
DOME & COURTESY LIGHTS

DUAL BEAM
HIGH BEAM
TURN SIGNAL
PARK LAMP
SIDE LIGHT
VOLTAGE REGULATOR
BLOWER MOTOR
HEATER SWITCH
BODY GROUND
BATTERY
ALTERNATOR
STARTER SOLENOID
COIL
HORN
OIL PRESS. SWITCH
REVERSE LIGHT SWITCH
NEUTRAL SAFETY SWITCH
AUTO TRANS SHIFTER LIGHT
IGNITION SWITCH
DISTRIBUTOR
CONDENSER
AUTO TRANS. KICKDOWN SWITCH
AUTO TRANS. SOLENOID
HAZARD FLASHER
FLASHER
HORN SWITCH
TURN SIGNAL & HAZARD SWITCH
GAUGE CLUSTER CONNECTOR
BRAKE FAILURE WARNING SWITCH
GLOVE BOX LIGHT & SWITCH
COURTESY LIGHT
DOOR SWITCH
CIRCUIT BREAKER FEED WIRES
CIGARETTE LIGHTER
IGN. SWITCH & CIG. LIGHTER LIGHT
BRAKE LIGHT
TAIL LIGHT
REVERSE LIGHT
BRAKE LIGHT
EXCEPT WAGON
TAIL LIGHT
LICENSE PLATE LAMP
DOME LIGHT (SEDAN/WAGON)
CARGO LIGHT (WAGON ONLY)
TRUNK LIGHT
CARGO LIGHT TAILGATE SWITCH (WAGON ONLY)
FUEL LEVEL SENDER
HEATER LIGHT
CLOCK & LIGHT
DOOR SWITCH
HEADLIGHT SWITCH
COURTESY LIGHT
TAIL LIGHT
EXCEPT WAGON
BRAKE LIGHT
REVERSE LIGHT
TAIL LIGHT
BRAKE LIGHT
HORN
HORN RELAY
BRAKE LIGHT SWITCH
FUSE BLOCK
PARKING BRAKE SWITCH
PARKING BRAKE WARNING LIGHT
WIPER SWITCH FEED
ASHTRAY LIGHT
HEADLIGHT WARNING BUZZER
TURN SIGNAL
PARK LAMP
HIGH BEAM
DUAL BEAM
SIDE LIGHT
TEMP. SENDER
DIMMER SWITCH

CINCO

1969 AMC REBEL
DASHBOARD PRINTED CIRCUIT BOARD



GAUGE CLUSTER
(VIEW FROM REAR)

A	TO DIMMER SWITCH (HIGH BEAM IND.)
B	TO TURN SIG. SWITCH (RIGHT)
C	TO BRAKE FAIL SWITCH
D	TO FUEL SENDER
E	TO OIL PRESS. SWITCH
F	TO FUSEBOX (POWER FEED)
G	TO ALT. VOLTAGE REG. (CHARGE LAMP)
H	TO GROUND
J	TO TEMP. SENDER
K	TO TURN SIG. SWITCH (LEFT)
L	TO HEADLIGHT SWITCH (INST. LIGHTS)

CINCO